

PrepAwayExam

PrepAwayExam

> Contact Us

Login / Register

Search...



HOME

ALL VENDORS

★ GUARANTEE

? FAQ

TESTIMONIALS

CART (0)

Pass Your Next Certification Exam Fast!

Everything you need to prepare, learn & pass your certification exam easily.

365 days free updates. First attempt guaranteed success.

Try **Online Engine** before you buy

Instant Download



After Payment, our system will send you the products you purchase in mailbox in a minute after payment. If not received within 2 hours, please contact us.

365 Days Free Updates



Free update is available within 365 days after your purchase. After 365 days, you will get 50% discounts for updating.



Money Back Guarantee

Full refund if you fail the corresponding exam in 60 days after purchasing. And Free get any another product.



Security & Privacy

We respect customer privacy. We use McAfee's security service to provide you with utmost security for your personal information & peace of mind.

<http://www.prepawayexam.com/>

High-efficient Exam Materials are the best high pass-rate Exam Dumps

Exam : HP0-066

Title : Advanced Lights Out

Vendors : HP

Version : DEMO

NO.1 When does iLO request its IP address from the DHCP server, provided this option is enabled?

- A. after the server completes its POST
- B. after power is first applied to the iLO
- C. after the operating system successfully boots
- D. after the iLO ROM-Based Setup Utility prompt displayed during server POST disappears

Correct: B

NO.2 How many concurrent non-Remote Console user connections does iLO allow?

- A. 1
- B. 2
- C. 10
- D. 12

Correct: C

NO.3 After removal of the iLO Diagnostic Port cable on a server blade, you immediately attempt to connect to the same iLO through the iLO management port in the rear of the server blade enclosure. The connection fails. Why?

- A. You must reset the iLO to enable the rear iLO management port.
- B. You must re-enable the rear iLO management port before disconnecting from the iLO Diagnostic Port.
- C. You must allow at least one minute for the network switchover between the iLO Diagnostic Port and the rear iLO management port.
- D. You must log out and terminate your browser session before disconnecting from the iLO Diagnostic Port.

Correct: C

NO.4 When connected to a Linux server with the iLO Remote Console, some of the POST messages requiring your response do not display during the boot process. How can you remedy this situation?

- A. Disable the Terminal Services Pass-Through option.
- B. Edit the startup script to allow more time for keyboard input.
- C. Disable the iLO Remote Console High Performance Mouse option.
- D. Configure the iLO to refresh the Remote Console text window at a higher rate using the

Remote

Console Text Refresh option.

Correct:B

NO.5 Which alert will the iLO 2 generate when it detects that a server blade was unable to power on because the BL p-Class infrastructure indicated that insufficient power was available to power on the server blade?

- A.Rack Server Power On Failed
- B.Rack Server Power On Halted
- C.Rack Server Power On Delayed
- D.Rack Server Power Oversubscribed

Correct:A

NO.6 What does the sequential flashing pattern of the iLO 2 LEDs 1-8 indicate?

- A.iLO 2 runtime failure
- B.iLO 2 hardware failure
- C.iLO 2 normal operation
- D.iLO 2 in flash recovery mode

Correct:D

NO.7 Which alert will the iLO 2 generate when it detects that a server blade was manually forced by the customer to power on despite the BL p-Class infrastructure reporting insufficient power?

- A.Rack Server Power On Failed
- B.Rack Server Power On Forced
- C.Rack Server Power Oversubscribed
- D.Rack Server Power On Manual Override

Correct:D

NO.8 What happens when iLO loses its connection to the directory server?

- A.It immediately sends an alert to the HP SIM server.
- B.It terminates the connection and returns you to the Login screen.
- C.It disables the Enable Directory Authentication option and forces you to use the local accounts.
- D.It displays the Directory Server unavailable message and tries to reconnect at 90-second intervals.

Correct:B

NO.9 When activating the iLO Virtual Media applet, the Virtual Media window displays a red X or a gray blank screen. Why?

- A.The iLO Advanced Pack license is not activated.
- B.The Virtual Media feature is disabled in the iLO Global Settings tab.
- C.The iLO did not detect any supported floppy or CD-ROM drives in the server.
- D.An incorrect version of or no Java Virtual Machine (JVM) is installed on the client.

Correct:D

NO.10 You have requested, obtained, and imported into iLO a certificate from a trusted Certificate

Authority (CA). However, your login into iLO using the two-factor Smart Card authentication fails.

Why?

- A.The Directory Services server cannot be contacted.
- B.The certificate is not mapped to a local user account.
- C.The Enable Directory Authentication option is turned off.
- D.The certificate was invalidated when the iLO was reset.

Correct:B